




## To calibrate the LMI 200W:

1. With the probe fully extended, click on the CAL LO button on the left hand side of the window, then press the SAMPLE button on the right hand side of the window.
2. With the probe fully retracted (all the way in), click on the CAL HI button on the left hand side of the window, then press the SAMPLE button on the right hand side of the window.
3. If the Low and High calibration is good, the software will automatically advance to the CAL Master position. Insert the probe all the way into the Mastering block and press the SAMPLE button.



4. Click the UPDATE button and exit close the window in order to save the calibration info within the probe. The LED on the probe will flash rapidly, indicating that it is turning off.
5. Close down Wireless Utility.

For a video demonstration of this process, please visit <http://youtu.be/-hmjqzZhHIE>.